

# PNEUMATIC CARTON STAPLER


MODEL:

**AIR 27**

MANUAL

## **WARNING**

BEFORE OPERATING THIS STAPLER. ALL OPERATORS SHOULD STUDY THIS MANUAL, TO UNDERSTAND AND FOLLOW THE SAFETY WARNINGS AND INSTRUCTIONS. KEEP THESE INSTRUCTIONS WITH THE STAPLER FOR FUTURE REFERENCE. IF YOU HAVE ANY QUESTION, CONTACT YOUR DISTRIBUTOR.



# TABLE OF CONTENTS

TOOL SPECIFICATIONS.....	2
SAFETY INSTRUCTIONS.....	3
LUBRICATION AND MAINTENANCE .....	4
AIR SUPPLY AND CONNECTIONS .....	4
LOADING THE TOOL .....	5
CHECK STAPLE LEG LENGTH .....	6
CLINCH ADJUSTMENT .....	7
DEPTH ADJUSTMENT .....	7
OPERATING THE TOOL .....	8
CLEANING THE TOOL .....	9
CLEARING A JAM FROM THE TOOL .....	10
TROUBLESHOOTING .....	11
TEETH REPLACEMENT .....	12
DRIVER REPLACEMENT .....	13
VALVE'S AND TUBE'S O'RINGS REPLACEMENT .....	14
PISTON REPLACEMENT .....	15
PISTON REPLACEMENT.....	16
PARTS LIST .....	17
EXPLODED VIEW OF TOOL .....	18

# TOOL SPECIFICATIONS

MODEL OF TOOL .....

DIMENSIONS (LENGTH \* HEIGHT \* WIDTH) ..... 410MM \* 220MM \* 115MM

WEIGHT (WITHOUT FASTENERS) ..... 2.65KG

AIR INLET ..... 1/4" NPT

**COMPRESSED AIR :**

MAXIMUM PERMISSIBLE OPERATING PRESSURE..... 8KG/CM<sup>2</sup>

RECOMMENDED OPERATING PRESSURE ..... 5KG/ CM<sup>2</sup> –7KG/CM<sup>2</sup>

AIR CONSUMPTION .....0.067 M<sup>3</sup>/MIN (2.4 C.F.M) WITH

60 STAPLES PER MINUTE

@5.66KG/ CM<sup>2</sup> (80 PSI)

STAPLES SPECIFICATION ..... CROWN

LENGTH 15MM,18MM.

STAPLES CAPACITY ..... 1000 PCS

THE NOISE LEVELS : (AT THE WORKPLACE, ALWAYS WEAR HEARING PROTECTION EQUIPMENT.)

A - EIGHTED SINGLE-EVENT SOUND PPRESSURE LEVEL AT OPERATOR'S POSITION:L pA, 1s = 89 dBA

A - WEIGHTED SINGLE-EVENT SOUND POWER LEVEL .....      L WA, 1s = 93 dBA

A - WEIGHTED SINGLE-EVENT SURFACE SOUND PRESSURE LEVEL ..... L Pa, 1s, 1m= 80 dBA

# SAFETY INSTRUCTIONS

## DANGER

1. READ THIS MANUAL AND UNDERSTAND ALL SAFETY INSTRUCTIONS BEFORE OPERATION THE TOOL. IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT OUR AUTHORIZED REPRESENTATIVES.
2. NEVER ALLOW TO USE TYPE OF FLAMMABLE GASES OXYGEN AS A POWER SOURCE FOR THE TOOL. USE FILTERED, LUBRICATED, REGULATED COMPRESSED AIR ONLY.
3. NEVER USE GASOLINE OR OTHER FLAMMABLE LIQUIDS TO CLEAN THE TOOL VAPORS IN THE TOOL WILL IGNITE BY A SPARK AND CAUSE THE TOOL TO EXPLODE.
4. DO NOT EXCEED MAXIMUM PERMISSIBLE OPERATING PRESSURE OF THE TOOL (8 KG/Cm<sup>2</sup>)
5. DISCONNECT THE TOOL FROM AIR SUPPLY BEFORE CLEANING JAMS, SERVICING, ADJUSTING, AND DURING NON-OPERATION.

## WARNING

6. DO NOT PULL THE TRIGGER WHEN CARRYING OR HOLDING THE TOOL. NEVER CARRY THE TOOL BY THE HOSE OR PULL THE HOSE TO MOVE THE TOOL.
7. AT THE WORKPLACE, ALWAYS WEAR THE PROTECTIVE EQUIPMENT SUCH AS SAFETY GLASSES, HEARING PROTECTION AND HEAD PROTECTION.
8. DO NOT USE A CHECK VALVE OR ANY OTHER FITTING WHICH ALLOWS AIR TO REMAIN IN THE TOOL.
9. DO NOT PLACE YOUR HAND OR ANY PART OF YOUR BODY IN THE STAPLE CLINCHING AREA OR ADJUSTMENT WINDOW OF THE TOOL WHEN CONNECTING OR DISCONNECTING AIR SUPPLY.
10. NEVER POINT ANY OPERATIONAL DRIVING TOOL AT YOURSELF OR AT ANY OTHER PERSON.

# LUBRICATION AND MAINTENANCE

## NOTE

YOUR TOOL REQUIRES LUBRICATION BEFORE YOU USE IT FOR THE FIRST TIME.

DISCONNECT THE AIR SUPPLY FROM THE TOOL BEFORE LUBRICATING.


TURN THE TOOL SO THE INLET IS FACING UP AND PUT ONE DROP OF HIGH SPEED SPINDLE OIL, UNOCAL RX22, OR 3-IN-1 OIL INTO AIR INLET. NEVER USE DETERGENT OIL ADDITIVES. OPERATE THE TOOL BRIEFLY AFTER ADDING OIL.

WIPE OFF EXCESSIVE OIL AT THE EXHAUST, EXCESSIVE OIL WILL DAMAGE ORINGS OF TOOL. IF IN-LINE OILER IS USED. MANUAL LUBRICATION THROUGH THE AIR INLET IS NOT REQUIRED ON A DAILY BASIS.

# AIR SUPPLY AND CONNECTIONS

## NOTE


THE FOLLOWING ILLUSTRATION SHOWS THE CORRECT MODE OF CONNECTION TO THE AIR SUPPLY SYSTEM WHICH WILL INCREASE THE EFFICIENCY AND USE. FULL LIFE OF THE TOOL.




MANY AIR TOOL USERS FIND IT CONVENIENT TO USE OILER TO HELP PROVIDE OIL CIRCULATION THROUGH TOOL AND INCREASE THE EFFICIENCY AND USEFUL LIFE OF THE TOOL. CHECK OIL LEVEL IN THE OILER DAILY.

MANY AIR TOOL USER FIND IT CONVENIENT TO USE A FILTER TO REMOVE LIQUID IMPURITIES WHICH CAN RUST OR WEAR INTERNAL PARTS OF THE TOOL. A FILTER ALSO INCEREASE THE EFFICIENCY AND USEFUL OF THE TOOL. THE FILTER MUST BE CHECKED ON A DAIL BASIS AND IF NECESSARY DRAINED.


## LOADING THE TOOL




DISCONNECT THE AIR SUPPLY



PRESS THE STOPPER (035), THEN PULL OUT THE PUSHER UNIT (032).




INSERT 2 STICKS OF APPROPRIATE STAPLES INTO THE MAGAZINE UNIT (029) FROM BACK. LET THE STICKS SLIDE FORWARD TO THE FRONT OF THE MAGAZINE UNIT (029).




REASSEMBLE THE PUSHER UNIT (026).

# CHECK STAPLE LENGTH

**NOTE : DISCONNECT THE AIR SUPPLY**



LOOSEN SET SCREW (526) WITH 3MM HEXAGON WRENCH KEY.




TURN ADJUSTING ROD (018) 180° WITH A SCREW DRIVER TO THE DESIRED ADJUSTMENT.

STAPLES LENGTHS	15MM	18MM
ROD POSITION	S — L	L — S

IF WANT TO SHOOT LONG LEG STAPLES. LET "L" ON ADJUSTING ROD (018) UP. IF WANT TO SHOOT SHORT LEG STAPLES. LET "S" ON. ADJUSTING ROD (018) UP.


STAPLES LENGTHS	18MM	22MM
ROD POSITION	S — L	L — S




TIGHTEN SET SCREW (526)

# CLINCH ADJUSTMENT

**NOTE : DISCONNECT THE AIR SUPPLY**




USE ROD(DIA 3 MM) OR 2.5 MM HEXAGON WRENCH KEY. TURN COLLAR (006) THROUGH WINDOW CLOCKWISE TO TIGHTEN CLINCH AND COUNTER-CLOCKWISE TO LOOSEN CHINCH.  
NOTE : REMOVE ADJUSTING TOOL AFTER ADJUSTMENT IS MADE.




# DEPTH ADJUSTMENT


**NOTE : DISCONNECT THE AIR SUPPLY**




LOOSEN FRONT SCREW (527) WITH 6 MM HEXAGON WRENCH KEY.



PUSH THE BODY (007) UP AND ADJUST TO DESIRED DEPTH.



WHEN TOP EDGE OF ADJUSTMENT PLATE (019) IS AT ITS HIGHEST SETTING (NO.4), THE TEETH (021,022) ARE AT THEIR SHALLOWEST PENETRATION. IF SET AT LOWEST SETTING (NO.1) THE TEETH (021,022) ARE AT THEIR DEEPEST PENETRATION.





# OPERATING THE TOOL

## WARNING


PROTECT YOUR EYES AND EARS. WEAR SAFETY GLASSES WITH SIDE SHIELDS. WEAR HEARING PROTECTION. EMPLOYERS AND USERS ARE RESPONSIBLE FOR ENSURING THE USER OR ANYONE NEAR THE TOOL WEAR THIS SAFETY PROTECTION.

## WARNING


TO PREVENT ACCIDENTAL INJURIES : NEVER, PLACE A HAND OR ANY OTHER PART OF BODY IN STAPLE CLINCHING AREA OR ADJUSTMENT WINDOW. NEVER POINT TOOL TOWARD ANYONE ELSE. NEVER ENGAGE IN HORSEPLAY. ALWAYS HANDLE THE TOOL WITH CARE. NEVER PULL TRIGGER UNLESS TOOL IS IN PLACE OF CARTON.

## NOTE


CHECK AND REPLACE ANY DAMAGED OR WORN COMPONENTS ON THE TOOL. THE SAFETY WARNING LABELS ON THE TOOL MUST ALSO BE REPLACED IF THEY ARE NOT LEGIBLE.




ADD A FEW DROPS OF UNOCAL RX22 OR 3-IN -1 OIL INTO THE AIR INLET.




INSTALL A QUICK CONNECT FITTING TO THE TOOL




REGULATE THE AIR PRESSURE TO OBTAIN 6 KG/cm<sup>2</sup> AT THE TOOL




INSERT STAPLES INTO YOUR TOOL FOLLOWING THE INSTRUCTIONS OF LOADING THE TOOL.




RECONNECT THE AIR HOSE TO THE TOOL



GRASP HANDLE WITH ONE HAND. POSITION ON BOX IN LINE WITH THE DESIRED STAPLE LOCATION. THERE IS A SMALL PROJECTION ON EITHER SIDE OF THE MAGAZINE SEAT (028) AS AN AID IN LOCATING THE POSITION OF THE STAPLE. PRESS TRIGGER (011) MOVE MACHINE TO NEXT STAPLE LOCATION WITH OR WITHOUT RELEASING TRIGGER.




STRONGEST CLOSURE REQUIRES END STAPLES CLOSE TO END OF BOX. CHECK PACKING REQUIREMENTS.




CHECK STAPLE CLINCHING IN SAMPLES OF BOX BOARD BEING USED. ADJUSTMENTS FOR DEPTH OF PENETRATION & TIGHTNESS OF CLINCH ARE EASY & INSTANTANEOUS, FULL ADVANTAGE SHOULD BE TAKEN OF THEM.

## CLEANING THE TOOL


### DANGER



NEVER USE GASOLINE OR OTHER FLAMMABLE LIQUIDS TO CLEAN THE TOOL. VAPORS IN THE TOOL WILL IGNITE BY A SPARK AND CAUSE THE TOOL TO EXPLODE AND RESULT IN DEATH OR SERIOUS PERSONAL INJURY.




1. DISCONNECT THE AIR SUPPLY FROM THE TOOL.




2. REMOVE TAR BUILDUP WITH KEROSENE #2 FUEL OIL OR DIESEL FUEL. DO NOT ALLOW SOLVENT TO GET INTO THE CYLINDER OR DAMAGE MAY OCCUR. DRY OFF THE TOOL COMPLETELY BEFORE USE.


## CLEARING A JAM FROM THE TOOL




DISCONNECT THE AIR SUPPLY.



TAKE OFF PUSHER UNIT (032) FROM MAGAZINE UNIT (029).



RELEASE MAGAZINE UNIT (029), WITH FLAT HEAD SCREW DRIVER, THEN CLEAR JAM.



REASSEMBLE MAGAZINE UNIT (029) AND PUSHER UNIT (032).

# TROUBLESHOOTING


## WARNING

**STOP USING THE TOOL IMMEDIATELY IF ANY OF THE FOLLOWING PROBLEMS OCCUR. SERIOUS PERSONAL INJURY COULD OCCUR. ANY REPAIRS OR REPLACEMENTS MUST BE DONE BY A QUALIFIED PERSON OR AN AUTHORIZED SERVICE CENTER ONLY.**


PROBLEM	CAUSE	REMEDY
AIR LEAKAGE FROM TRIGGER.	O-RINGS ON VALVE (016) OR ON TUBE (017) ARE DAMAGED.	O-RINGS MUST BE REPLACED.
AIR LEAKAGE FROM EXHAUST PORT.	O-RINGS ON VALVE (016) OR ON TUBE (017) ARE DAMAGED.	O-RINGS MUST BE REPLACED.
	PISTON'S O-RING (507) IS DAMAGED.	O-RING MUST BE REPLACED.
AIR LEAKAGE FROM CYLINDER.	PISTON ROD PORT O-RING IS DAMAGED.	REPLACE THE O-RING.
SLOW AND SHORT TRAVEL CYCLING	CHECK FOR LOOSE END SCREW (517) AND WEAR OF PARTS (014, 009)	POSITION ECCENTRIC PIN (013) AS SHOWN AND TIGHTEN SCREW (517) RECHECK, FOR MAXIMUM EFFICIENCY, SLIGHT ADJUSTMENT OF PIN AT THE POSITION SHOWN MUST BE MADE UPWARD DIRECTION IF SHORT TRAVEL OCCURS AND DOWNWARD DIRECTION IF SLOW CYCLING OCCURS.
EXCESSIVE JAMS:	SLOW AND SHORT TRAVEL CYCLING.	CHECK AS NOTED IN SLOW AND SHORT TRAVEL CYCLING SECTION.
	TEETH SCREWS LOOSE.	TIGHTEN SCREWS
	STAPLE SIZE IS WRONG.	USE THE PROPER SIZE STAPLE
	INSUFFICIENT LUBRICATION.	CLEANING AND LUBRICATION SUITABLY.
UNEVEN CLINCH	WRONG STAPLE SIZE.	CHECK FOR PROPER LEG LENGTH & ADJUSTMENT CLINCHER.
UNCLINCHED STAPLE	TEETH (021,022) LOOSE	TIGHTEN TEETH (021,022)
	TEETH (021,022) ARE	REPLACE TEETH (021,022)
	SLOW AND SHORT TRAVEL CYCLING.	CHECK AS NOTED IN SLOW AND SHORT TRAVEL CYCLING SECTION.

# TEETH REPLACEMENT


**NOTE : DISCONNECT THE AIR SUPPLY.**




TAKE OFF THE MAGAZINE UNIT (029) WITH FLAT HEAD SCREW DRIVER, THEN CLEAR JAM.



LOOSEN SCREWS (530) WITH 4 MM HEXAGON WRENCH KEY.




REMOVE THE MAGAZINE SEAT (028).




LOOSEN SCREWS (532) WITH 3 MM HEXAGON WRENCH KEY.  
CHANGE TEETH ONE AT A TIME TO PREVENT REVERSING TEETH.

# DRIVER REPLACEMENT


**NOTE : DISCONNECT THE AIR SUPPLY.**




TAKE OFF THE MAGAZINE UNIT (029) WITH FLAT HEAD SCREW DRIVER, THEN CLEAR JAM.




LOOSEN SCREWS (530) WITH 4 MM HEXAGON WRENCH KEY.




REMOVE THE MAGAZINE SEAT (028)



LOOSEN SET SCREW (526) WITH 3 MM HEXAGON WRENCH KEY TO UNLOCK ADJUSTING ROD (018)



SLIDE LINKAGE MECHANISM AND ADJUSTING ROD (018) SIMULTANEOUSLY FROM COLLAR (006).




LOOSEN SCREWS (535) WITH 3 MM HEXAGON WRENCH KEY. TAKE OFF THE SPRING PIN (537) WITH HAMMER AND 6 MM STRAIGHT ROD.


## VALVE'S AND TUBE'S O-RINGS REPLACEMENT

**NOTE : DISCONNECT THE AIR SUPPLY**


LOOSEN SCREWS (513) WITH FLAT SCREW DRIVER.




REMOVE SPRING (012) WITH LONG NOSE PLIERS.




REMOVE C-RING (546) WITH A C-RING PLIER.



REMOVE VALVE (017) AND TUBE (016) WITH A LONG NOSE PLIERS.




## PISTON REPLACEMENT




**NOTE : DISCONNECT THE AIR SUPPLY**


REMOVE THE MAGAZINE ASSEMBLY ( 029 ) WITH A FLAT HEAD SCREW DRIVER.




REMOVE SCREWS ( 530 ) WITH 4 mm HEXAGON WRENCH KEY .




LOOSEN SET SCREW ( 526 ) WITH 3 mm HEXAGON WRENCH KEY TO UNLOCK ADJUSTING ROD ( 018 ) .




SLIDE LINKAGE MECHANISM AND ADJUSTING ROD ( 018 ) SIMULTANEOUSLY FROM COLLAR ( 006 ) .




LOOSEN SPRING PIN ( 511 ) WITH 3 mm STRAIGHT ROD, THEN REMOVE COLLAR ( 006 ) AND SPRING ( 005 ) .



LOOSEN SCREW ( 510 ) WITH 3 mm HEXAGON WRENCH KEY TO REMOVE BLOCK ( 004 ) THROUGH WINDOW .



LOOSEN SCREWS ( 501 ) WITH 3 mm HEXAGON WRENCH KEY . REMOVE CAP ( 001 ) .



REMOVE PISTON ASSEMBLY . LOOSEN NUT ( 504 ) WITH 10 mm SPANNER .  
REMOVE PISTON ( 002 ) AND EXCHANGE A NEW ONE



MODEL :

Item	Parts No.	Description	Q'ty	Specification
001	A01200110	CAP	1	NO MARK
001	A01200111	CAP	1	SACA
002	A02800201	PISTON	1	
003	A02800301	PISTON ROD	1	
004	A00100401	BLOCK	1	
005	A00100501	SPRING	1	
006	A00100601	COLLAR	1	
007	A01200403	BODY	1	
008	A00100801	AIR PLUG	1	Japanese Type
008	A00100802	AIR PLUG	1	U.S.A. Type
008	A00100803	AIR PLUG	1	European Type
009	A00100902	BLOCK	1	
010	A00101001	SPRING	1	
011	A00101101	TRIGGER	1	
012	A00101201	SPRING	1	
013	A00101301	ROD	1	
014	A00101402	TRIGGER'S CONTROL	1	
015	A00101501	SPRING	1	
016	A00101601	VALVE	1	
017	A00101702	TUBE	1	
018	A00101801	ADJUSTING ROD	1	
019	A00101901	ADJUSTING PLATE	1	
020	A00102501	FRONT PLATE	1	
021	A00102102	RIGHT TEETH	1	19mm
021	A01200501	RIGHT TEETH	1	22mm
022	A00102202	LEFT TEETH	1	19mm
022	A01200601	LEFT TEETH	1	22mm
023	A00102301	TEETH SEAT	2	
024	A00102401	PLATE	2	
025	A00102502	BLOCK	1	
026	A00102605	DRIVER	1	19-35, 9040, 7437
026	A01201706	DRIVER	1	19-32
026	A01201709	DRIVER	1	22-32
026	A00102604	DRIVER	1	19-34
026	A01201708	DRIVER	1	22-35 (71.2mm)
027	A00102703@	COVER UNIT	1	
028	A01101402	MAGAZINE SEAT	1	
029	HA-19-35-P2	MAGAZINE	1	19-35
029	HA-19-32-P2	MAGAZINE	1	19-32
029	HA-19-34-P2	MAGAZINE	1	19-34
029	HA-22-35-P2	MAGAZINE	1	22-35
029	HA-22-32-P2	MAGAZINE	1	22-32
029	HA-9040-P2	MAGAZINE	1	9040
029	HA-7437-P2	MAGAZINE	1	7437
030	A01102403	SPRING	2	
031	A01102201	BRACKET	1	
032	A01101801	PUSHER	1	19-35, 22-35
032	A01101802	PUSHER	1	19-34
032	A01101803	PUSHER	1	19-32
032	A01101804	PUSHER	1	9040, 7437

20050802

Item	Parts No.	Description	Q'ty	Specification
033	A01102001	ROD	1	
034	A01102101	SPRING	1	
035	A01101901	STOPPER	1	
036	A00105001	WASHER	2	
051	BA11401	SILENCER	1	
501	BAC0604142	HEX.SOC.HD.BOLT	4	M4 x 0.7-14
503	BAB017537	O-RING	1	ψ1.78 x ψ53.7
504	BAD02061	HEX.NUT	1	M6 x 1
505	BAT03061	WASHER	1	1/4" x 5/8" x 1T
506	BAB017076	O-RING	1	ψ1.78 x ψ7.65
507	BAB057476	O-RING	1	ψ5.7 x ψ47.6
508	A00104101	WASHER	1	ψ8 x ψ23 x 1.6T
509	BAE01042	SPRING WASHER	1	M4
510	BAC0404062	HEX.SOC.HD.BOLT	1	M4 x 0.7-6
511	BAA025014	SPRING PIN	1	ψ2.5-14
512	BAC0312122	HEX.SOC.HD.LESS.BOLT	1	M12 x 1.75-12
513	A00104401	TRIGGER SCREW	2	M4 x 0.7-7
514	BAE01042	SPRING WASHER	2	M4
515	BAA030020	SPRING PIN	1	ψ3-20
516	BAE02042	OUTSIDE TEETH WASHER	1	M4
517	BAC0404102	HEX.SOC.HD.BOLT	1	M4 x 0.7-10
518	BAA030010	SPRING PIN	1	ψ3-10
519	BAB017124	O-RING	1	ψ1.78 x ψ12.42
520	BAB017076	O-RING	2	ψ1.78 x ψ7.65
521	BAB016145	O-RING	1	ψ1.6 x ψ14.5
522	BAB016150	O-RING	1	ψ1.6 x ψ15
523	BAB016155	O-RING	1	ψ1.6 x ψ15.5
524	BAB016160	O-RING	1	ψ1.6 x ψ16
525	A00104701	ROD	2	ψ4.9-17.5
526	BAC0306142	HEX.SOC.HD.LESS.BOLT	1	M6 x 1-14
527	BAC0408162	HEX.SOC.HD.BOLT	1	M8 x 1.25-16
528	BAE01082	SPRING WASHER	1	M8
529	BAA030010	SPRING PIN	4	ψ3-10
530	BAC0605142	HEX.SOC.HD.BOLT	2	M5 x 0.8-14
532	BAC0205122	HEX.SOC.FLAT COUNTER SUNK HD.SCREW	2	M5 x 0.8-12
533	A00104501	PIN	4	ψ3.97-13
534	A00104602	PIN	2	ψ6.05-8
535	BAC0604102	HEX.SOC.HD.BOLT	2	M4 x 0.7-10
537	BAA060016	SPRING PIN	2	ψ6-16
538	BAD01051	LOCK NUT	1	M5 x 0.8
539	BAD01051	LOCK NUT	1	M5 x 0.8
540	BAF22002	C-RING	1	ψ20
541	BAF10252	E-RING	1	ψ2.5
542	BAG010602	HELI-COIL	1	M6x1.0-2D
543	A00104901	PLASTIC PIN	1	
544	C0011201	COUNTER BALANCE HANGER	1	
545	BAF22002	C-RING	1	ψ20
546	BAC0204062	HEX.SOC.FLAT COUNTER SUNK HD.SCREW	1	M4 x 0.7-6

